

COMPACTOR REFURBISHMENT by Pinnacle Compactors

- Save money and bring your old equipment back to life
- Units are fully evaluated and level of service recommended
- Pinnacle compactor inventory available upon request



BEFORE



AFTER



- Refurb services available for Pinnacle and other main brands
- New and dedicated facility at the BWE plant in NC



**SCAN TO SEE
IN ACTION!**

PinnacleCompactors.com

SERVICE LEVEL **1** 30 Day Warranty

- Minor patch repairs as needed
- Power Unit – Inspection of unit including diagnostics on operating system and load test – make minor component replacements and repairs – change hydraulic oil & filters – ensure unit is in good, overall running condition
- Inspect cylinders for leaks and functionality
- Inspect ram guides and ram tracking
- Inspect hydraulic hoses / fittings and replace if necessary
- Inspect / grease wear items such as ground wheel, nose rollers, door seals, etc. and replace as necessary
- QC, test, and water test to ensure compactor is in good running condition
- Repaint, apply ANSI Safety Decals, and stage for deployment

SERVICE LEVEL **2** 120 Day Warranty

- Inspect overall unit and structural integrity – includes patch & major repairs
- Inspect power unit – run diagnostics on operating system and load test – make minor component replacements and repairs – change hydraulic oil & filters – ensure unit is in good, overall running condition
- Inspect & replace with “rebuilt” cylinders (if necessary)
- Install new cylinder mounts & pins
- Install new cylinder hoses & fittings
- Inspect ram guides and ram tracking
- Inspect hydraulic hoses / fittings and replace if necessary
- Inspect / grease wear items such as ground wheel, nose rollers, door seals, etc. and replace if necessary
- QC, test, and water test to ensure compactor is in good running condition
- Prep Surfaces and Repaint, apply ANSI Safety Decals, and stage for deployment

SERVICE LEVEL **3** 12 Month Warranty

- Inspect overall unit and structural integrity – includes patch & major repairs
- Inspect power unit – run diagnostics on operating system and load test – make minor component replacements and repairs – change hydraulic oil & filters – ensure unit is in good, overall running condition
- Install / replace with “new” cylinders
- Install new cylinder mounts & pins
- Install new cylinder hoses & fittings
- Inspect ram guides and ram tracking
- Replace all hydraulic hoses / fittings
- Replace / grease all wear items such as ground wheels, nose rollers, door seals, etc.
- QC, test, and water test to ensure compactor is in good running condition
- Prep Surfaces and Repaint, apply ANSI Safety Decals, and stage for deployment



bwe-nc.com



pinnaclecompactors.com

1808 Norwood Street SW
Lenoir, NC 28645
828/726-3001 (phone)
828/726-3010 (fax)

800-221-4153